

1



Unscrew both bolts, one on each side of your toilet.*

2



Remove your toilet seat.

3



Put the *Totty Potty* base on your toilet.

4



Insert the adjustment plates.

5



Replace the toilet seat, and **screw** the bolts back on (through the adjustment plates). **DO NOT** tighten the bolts.

6



Flip the toilet lid up, and **plug in** the *Totty Potty* seat. **Tip:** The seat can be removed for easy cleaning.

7



For best results, **align** the *Totty Potty's* front hinges with your toilet seat's hinges by moving the base forward/backward.

8



Slightly rotate the adjustment arms to ensure the *Totty Potty* seat sits flat on the adult seat. **Tighten** both bolts.

* Removal of the toilet seat can vary depending on manufacturer. Please refer to your owner's manual for more information.